

Instructions for reading the Aidon 5511 and 5530 remotely read electricity meters

The electricity meter is read and its functions can be controlled via a remote connection.


Disconnecting the power supply to your home

- To disconnect the power supply to your home, you should primarily use the button on the switching device. In this way, the data transfer connection of the meter will not be disconnected and the readings can still be read remotely by Kymenlaakson Sähkö.
- **For the duration of electrical work, electricity must be disconnected from the main switch of the property and by removing the fuses for the work area.**
- Electricity can also be connected or disconnected via the remote connection.
- **Instructions for using the switching device (this text is displayed on the meter in Finnish)**

To connect or disconnect electricity, press the above button for about 1 second. For the duration of electrical work, electricity must be disconnected from the main switch of the property and the fuses for the work area should be removed.

Function of the indicator lights of the switching device

Indicator light of the switching device	Mode	Measures
The green light is illuminated	The electricity is connected.	
The green light is flashing	The electricity has been disconnected.	Press the main switch to reconnect the power supply.
The red light is flashing	The electricity is disconnected and connection is prohibited.	Contact Kymenlaakson Sähkö customer services. The electric meter is in this mode if the metering point has no service contract.
The red light is constantly illuminated	Equipment failure.	Contact Kymenlaakson Sähkö customer services.
The indicator lights are not on and there is nothing showing on the display of the electricity meter	There is no electricity supply to the metering device.	Check that the main switch is on (position I) and the fuses are intact and in place.



Reading your own consumption on the electricity meter

- With single-rate metering (normal domestic electricity), the total energy used is shown on the display. You can also view the time and date on the display by using the scroll button.
- With dual-rate metering (night and seasonal electricity), the data presented in the following table, flashes on the display. The total consumed energy can also be viewed by using the scroll button.

General electricity	General electricity, using the scroll button
1. Total energy	1. Total energy 2. Date 3. Time

Night and seasonal electricity	Night and seasonal electricity, using the scroll button
1. Night energy / other time (T1/T3) 2. Day energy / winter weekday (T2/T4) 3. Active metering method* 4. Date 5. Time	1. Total energy 2. Night energy / other time (T1/T3) 3. Day energy / winter weekday (T2/T4) 4. Active metering method* 5. Date 6. Time

*) Active (i.e. current) metering method is shown on the display as follows:

01 means metering method T1 and 02 means metering method T2.

03 means metering method T3 and 04 means metering method T4.

If you buy night-time electricity from us (or seasonal electricity) electrical appliances, such as water heaters, are switched on with a variable delay of between 1–60 minutes after 10 pm. Despite the connection delay, energy metering for the cheaper rate is switched on at the contracted time (i.e. 10pm).

Kymenlaakson Sähkö customer service, tel. 05 7780 500, open Mon–Fri 8am–5pm.